


Leica FAQ

How do I change an RTK rover's Height of Instrument (HI) after I've downloaded it into SKI-Pro?


Answer:

- Go to the View/Edit window in SKI-Pro.
- Right-click on the rover point in question.
- Select Edit Interval (see display below).




Changing RTK rover's HI

- An Interval Properties (Point) window opens (see display below).



- Change the HI in the “Height Reading” field.
- A warning window appears(See Below).



- If the changed height is acceptable, press the **OK** button to accept the new height.

Changing RTK rover's HI