

*I modified the configuration of my System 500 GPS receiver using the CONFIG button, but when I turned my receiver back on all my changes were gone. How do I make my modifications permanent?*

**Answer:**



There are two ways to modify a configuration. You can access a configuration to make modifications by

- 1) Pressing the **CONFIG** button or by
- 2) Selecting menu item **6 Configure** from the MAIN\ menu screen.



Figure 1.

If you edit a configuration using the **CONFIG** button, the changes are temporary. To make these changes permanent, return to the MAIN\ menu and press the **CONFIG** and **F3 (STORE)** button (see below).

Step	Action	Display
1	<p>From the MAIN\ menu screen:</p> <ul style="list-style-type: none"> <li>• Press the <b>CONFIG</b> button.</li> </ul> <p>This opens the CONFIGURE\ window.</p>	
2	<p>In the CONFIGURE\ screen:</p> <p>Press the <b>F3 (STORE)</b> button.</p> <p>This will permanently store your configuration modifications.</p>	

If you edit a configuration by accessing it via the **6 Configure** (see Figure 1), the edits will be stored permanently.